


WIRING DIAGRAMS

For PWV 1000 vertical windlass



For vertical and horizontal PW 500 windlasses

